



1. Structura produsului



Față



Spate

Placa de fixare

Instructiuni de utilizare


- 1) PIR(Sensor Piroelectric Infraroșu): În cazul în care există mișcare în fața soneriei, un mesaj text sau apel va fi trimis către telefon
- 2) IR night vision: se activează automat dacă lumina este mai mică de 2 Lux
- 3) Microfon: recepționează sunet și voce pentru intercom
- 4) Tasta: pornește dispozitivul, notifică gata ca are vizitator și conectează soneria
- 5) Lentila: camera video
- 6) Indicator lumina:
 - (a) Lumina albastră intermițentă înseamnă: dispozitivul așteaptă conectarea WIFI
 - (b) Lumina albastră intermițentă pentru 5 secunde: sistemul funcționează corect după apăsarea tastei soneriei
 - (c) Lumina roșie intermițentă pentru 5 secunde: conexiunea WIFI nu a reușit după apăsarea tastei soneriei
 - 7) Difuzor: pentru intercom și mesaje audio
 - 8) Sursă: pentru siguranța dispozitivului contra furtului
 - 9) Resetare: pentru resetarea dispozitivului
 - 10) Baterie: pentru 2 baterii 18650 mao
 - 11) Conexiune electrică: pentru conectarea la rețeaua electrică
 - 12) USB: pentru încălzirea electrică a dispozitivului
 - 13) Conexiune electrică externă: conexiune la rețeaua electrică
 - 14) Slot pentru fișier
 - 15) Gaură pentru suruburi

Instructiuni pentru conectarea la sursa electrică externă


- 1) Introduceți firul negativ și pozitiv AC/DC 8V-24V în locașul fir și înșurubați bine.
- 2) Fixați capacul spate și instalați dispozitivul după ce faceți 4 gauri în perete sau ușă
- 3) Fixați bine dispozitivul pe capacul spate




Instalare



1) Scoateți capacul spate




2) Fixați capacul spate pe perete



- 1) Fixați capacul spate pe perete cu șuruburile furnizate sau (șuruburi 3M (nu este inclus în pachet))
- 2) Conectați cablul AC (nu este inclus în pachet) la sursa electrică externă

Conectarea dispozitivului


- 1) Descărcați aplicația "AnyBell" din App Store sau Google Play
- 2) Poniți dispozitivul și așteptați mesajul vocal "Dispozitivul este gata să se conecteze la rețeaua WiFi"




- 3) Nu uitați să verificați dacă dispozitivul este în mod pairing. Așteptați mesajul vocal "Dispozitivul este gata să se conecteze la rețeaua WiFi"



- 5) Numele rețelei WIFI de vă completați automat. Introduceți parola. Setarea volumului la maximum. Telefonul trebuie să fie pe rețeaua WIFI 2.4G




- 4) Dacă nu auziți comanda vocală, apăsați 3 secunde tasta reset. Lumina albastră se aprinde și dispozitivul se resetează



- 6) Telefonul începe să emită sunete pentru setarea. Presetați înțeles. Dispozitivul trebuie să se conecteze la rețeaua la fel de 30 sec



- 7) După conectarea cu succes la rețea, introduceți numele dispozitivului în parolă. Aceasta trebuie să conțină minimum 8 caractere, formata din litere, numere și semne



Specificatii

Rezoluție	1280x720
Lentila	166 grade
Infraroșu night vision	6 dispozitive 850mm
WIFI	suport 802.11b/g/n
Audio	suportă comunicație
Investigare	canal MicroSD
Memorie	pana la 32 GB
Baterie	2 bucăți 18650
Notificare	in doua secunde
Time Wake-Up	cca 600 milisekunde
Wake-Up prin apăsarea butonului	18650
Consum energie electrică	200 mA
Current de lucru	170 mA

Q&A


- Q: conexiunea WIFI nu funcționează
asigurați-vă că telefonul este conectat la rețeaua 2.4G WIFI, nu la 5G WIFI
asigurați-vă că lumina albastră clipește intermițent înseamnă
asigurați-vă că parola este corectă și că nu există spații goale între caractere
- Q: telefonul nu primește notificări când dispozitivul este conectat și detectează activitate
activat "AutoStart" și "Notification", Opți: "Battery Saver"

- Q: cum să văd de energie suportă dispozitivul?
- 1) Baterie
 - 2) Curent AC 8-24V
 - 3) Incarcare cu cablu USB




LOW POWER WIFI VIDEO DOORBELL

1.Product Structure



Front



Back

Retainer plate


2.Basic Instructions/APP

- PIR(Pyroelectric Infrared Sensor): There will be a message or call sent to mobile phone if somebody moving before the device.
- IR night vision: It will turn on when luminance less than 2Lux.
- Mic: Sound collecting and voice intercom
- Button: Turn on the device, notify visitor to the user and connect
- Dingdong: Dingdong
- Lens: Video collecting
- Indicator:
 - (1)The system is waiting for WIFI connecting when blue indicator slow flash
 - (2)The system is working correctly after pressing the doorbell and blue indicator flash 5S.
 - (3) The system connected with WIFI failed after pressing the doorbell and red indicator flash 5S.
- Speaker: System prompt and voice intercom.
- Anti-theft cover: To avoid the device be disassembled.
- Reset: To reset the device in the case of a system jam or crash.
- Battery: Install 18650 battery
- External Power: Connect the external power hole to get electricity.
- USB: Charge the device.
- External power hole: Connect it with AC power inside wall to supply power to the device.
- Slot: Install the device to the bracket.
- Fixed hole: Install the bracket to the wall with screw.


- Ding Dong Bell: This doorbell supports external ding dong bell.(Ding dong bell needs to be purchased additional.)
- How to connect the external power cable:
(1)Insert the AC/DC 8V-24V negative wire and positive wire to the fixed hole and tighten it.
(2)Fix the back cover of doorbell and install the doorbell after punching 4 holes on the wall or door.
(3)Tighten the bell with fixed cover.




3.Install



Step 1 : Take out the back cover .




Step 2: Fix the back cover of doorbell on the wall




- (1)Install the back cover on the wall by screw (Standard Accessories) or paste it on the glass with 3M sticker.(not included in standard accessories).
- (2)Connect the AC(8-24V) wire (not included in standard accessories)to the external power hole by electric conduction screw.

4.Connect the device.

- (1)Please download the "AnyBell" in Apple store or Google Play Store(Please open it, notify messages to get better user experience.)
- (2)Connect the device with power, and wait for the voice prompt "Device is ready to pairing". Note: Your phone should be connected with WIFI successfully.




- (3)Reset: make sure the device is in pairing mode when setting up. Then you will hear the voice prompt.
- (4)Please press the reset button 5S after turning on the device if you don't hear the voice PIR ring. The blue indicator will turn on which means the device is being reset.




- (5)The WIFI network name will be filled in automatically, then input the password. Please set the alarm of your phone medium. Note: Make sure mobile phone is connected with 2.4G WIFI, NOT 5G WIFI.
- (6)Please keep quiet when mobile phone emits sound waves. And make sure the distance is around 30cm between phone and doorbell to wait for connecting the network.




- (7)After 10S in the device name and password after connecting the network successfully. The password must be at least 8 characters include capital, lower-case letters and numbers.



- (8)Please keep quiet when mobile phone emits sound waves. And make sure the distance is around 30cm between phone and doorbell to wait for connecting the network.



- (9)Please keep quiet when mobile phone emits sound waves. And make sure the distance is around 30cm between phone and doorbell to wait for connecting the network.



5.Specification

Resolution	1280x720
Lens	166-degree
IR night vision	6 pieces 850mm
WIFI	Support 802.11b/g/n
Audio	Support talkback
Record	Micro SD card
Memory	8GB/16GB/32GB
Battery	2 pieces 18650 batteries
Notification	Within 2S
Wake-up time	Within 600ms
Wake-up	mode Button
Power Consumption	200uA
Working current	170mA

6.Q&A

- Q: Can not connect WIFI
A.1. Please make sure mobile phone is connected 2.4G WIFI, not 5G WIFI.
3. Please make sure the password is right and there is no space between letters.
Q: Mobile phone can not receive the notifications when device is online and detected something happened.
A: Turn on "AutoStart" and "Notifications" - Turn off "Battery saver" .
Q: What power supply made the device support?
A.1. Battery.
2. AC(8/24V)external power .
3. Charge with USB cable.



LOW POWER WIFI VIDEO DOORBELL

折页 正反两面